

**Small Dirt spots on Prints
IT Belt Cleaning**

If you encounter small dirt spots i.e. like on the example print below and the spot persists in almost the same position maybe just move very little in vertical direction, please follow the instruction below.



- 1) Enter Service Mode by turning on the Power while pressing the 'ENTER' button and 'CONTINUE' button at the same time. Hold buttons pressed until 'SERVICE MODE' is shown on LCD Display.
- 2) Press 'MENU/EXIT' button. (Then 'SERVICE REPORT' is displayed)
- 3) Press 'CANCEL' button. (Then 'MAINTENANCE' is displayed)
- 4) Press 'ENTER' button. (Then 'CLEAN ACCUMULATOR BELT' is displayed.
- 5) Press 'ENTER' button. (Then 'CLEANING 'WAIT 10 SEC"' is displayed.
- 6) When Cleaning is finished 'SERVICE MODE' will be displayed.
- 7) Now turn Power off/on. The Printer should initialize and go to 'READY'.

In case Problem persists please report via 'SpaceOne Problem' Form on www.themagictouch.com