

KX-P8415

How to reset the Counter for Cleaning Pad.

Press MENU

Press ▲ 2x > Maintenance

▶/ENTER

Press ▼ 1x > Counter Reset

▶/ENTER

Press ▼ 1x > New Cleaning Pad?

▶/ENTER

Press ▼ 1x > Yes

▶/ENTER

Printer will return to 'READY'

Done!